



DOSING NOZZLE CLOSURE

FUNCTION DESCRIPTION

The dosing nozzle closure prevents that residues of the granulate may fall out of the dosing nozzle when the drum is turned. The system is available for new machines as well as a retrofit kit for installed machines.

The dosing nozzle closure is installed on the dosing nozzle and fastened with a screw. The dosing nozzle closure is opened and closed by a tilt mechanism that is triggered by the rotary movement of the drum.

SCOPE OF DELIVERY

- Dosing nozzle closure
- Retaining plate
- Modified heating tube, if necessary
- Fixing material

TECHNICAL DATA

Measures	d 110 mm / H 45 mm
Weight	app. 0,6 kg

